Service 235 - CUTTING



Cutting

| item | Order No. |
|---|---------------|
| hose cut along the spiral | 235-0000-0000 |
| vertical hose cut | 235-0000-0800 |
| cutting, insulation remove, turn wire into hose | 235-0000-0900 |
| leading-out wire out of the sprue | 235-0000-0901 |
| wire bending (without insulation remove) | 235-0000-0902 |

Positive and negative pressure ratings are the recommended maximum operating values. Products can be manufactured to meet higher operating values upon request. The bend radius is calculated from the center of the hose in an arched position. Additional information at www.norres.com/us/technology/. NORRES reserves the right to modify technical data at any time. Technical data based on tests at 68°F and are approx. values. Proper use and maintenance of NORRES hoses is the sole responsibility of purchaser and ultimatives of variables make firm recommendations technically impossible. This information is intended as a general guide only.